SHARP

SHARP ELECTRONIC CASH REGISTER
CAJA REGISTRADORA ELECTRONICA DE SHARP

MODEL
MODELO

XE-A110
XE-A115

INSTRUCTION MANUAL

MANUAL DE INSTRUCCIONES



The above illustration shows model XE-A115.

[English]

Parts and Their Functions **4**
Mode Switch 4
Keyboard Layout 4
Display 5
Before Operation **5**
Reset the Cash Register 5
Install Batteries..... 6
Install the Paper Roll 6
Set the Time and Date 7
Check the Time and Date 8
Program Tax 8
Program Departments 10
Program PLUs 10
Program Other Items as Necessary 11
When an Error Occurs **11**
Error Escape Function..... 11
Typical Operation Examples **12**
When Paid by Cash 12
When Paid by a Credit Card 12
When Paid by Check..... 12
Mixed Tender Sale..... 13
Corrections **13**
Correction of Entered Numbers..... 13
Correction of the Last Entry (Direct Void) 13
Correction of Earlier Entries (Indirect Void) 14
Repetitive Entries..... **14**
Repetitive Department Entries 14
Multiplication Entries 14
Department **15**
Programming a Preset Unit Price 15
Programming the Department Status 15
Operation Using a Preset Unit Price 16
Single Item Cash Sale (SICS) Entry 16
PLU **17**
Programming..... 17
Entry 17
Tax Calculation **18**
Taxable Subtotal..... 18
Automatic Tax Calculation 18
Tax Shift 18
Tax Delete 19
Manual Tax 19
Opening the Drawer with No Sale **19**
Percent Key **19**
Programming Percent Key Function 20
Programming Percent rate 20
Discounts and Premiums Using the Percent Key 21
Minus Key (XE-A115 only) **21**
Programming a Preset Reduction Amount 21
Programming the Minus Key Status 22
Discounts Using the Minus Key 22

Non-add Code Number 23
Received-on-Account and Paid-Out Entries 23
Entering a Refund 23
Receipt Number 24
Printing Format 24
Miscellaneous Settings 25
Secret Code 26
Checking the Machine Settings 27
General & Tax Settings 27
PLU Settings 27
Reading and Resetting of Sales 28
X Reports for Reading of Sales 28
Z Reports for Reading and Resetting of Sales (without resetting GT) 28
Z Reports for Reading and Resetting of Sales (with resetting of GT) 28
Flash Reports for Viewing on the Display 28
Basic Calculator Function 30
Calculation Examples 30
Using the Memory Key 30
Drawer Handling 31
Locking the Drawer 31
Removing the Drawer 31
Manually Opening the Drawer 31
Maintenance 31
Batteries 31
Paper Roll 32
Ink Roller 33
In Case of Power Failure or Paper Jam 33
Before Calling for Service 34
Specifications 34

Español

Antes del funcionamiento 35
Ejemplos de funcionamiento 36
Sección 37
PLU 37
Cálculo de impuestos 37
Para abrir el cajón sin venta 38
Tecla de porcentaje 38
Tecla de "menos" (XE-A115 solamente) 38
Número de código de no suma 39
Registros de recibido a cuenta y pagos 39
Registro de una devolución 39
Número de recibo 39
Formato de impresión 39
Ajustes varios 39
Código secreto 40
Comprobación de los ajustes de la máquina 40
Lectura y reposición de las ventas 40
Función básica de calculadora 40
Mantenimiento 40

This is a “Table of Contents preview” for quality assurance

The full manual can be found at http://the-checkout-tech.com/estore/catalog/

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

http://the-checkout-tech.com : the biggest supplier of cash register and scale manuals on the net